

Extraction from EMMA

J. Scott Berg
Brookhaven National Laboratory
NFMCC Friday Meeting
28 November 2008

EMMA Introduction

- Linear non-scaling FFAG
- Accelerates electrons from 10 to 20 MeV KE
- Combined-function doublet lattice
- Different lattice configurations
 - Variable dipole and quadrupole
 - Quadrupoles on horizontal sliders

Extraction Goals

- Extract beam at all energies
 - Phase advance depends on energies
 - Two kickers in adjacent cells
- Extract beam anywhere within 3 mm acceptance
- Don't hit the vacuum chamber walls
- Keep kicker strengths below 0.6 T


Algorithm

- Given energy, take all particles on maximum ellipse
- Map all particles to same horizontal position
- Minimize kick strength
- Constrained by pipe aperture, if possible


Vacuum Chamber

- F magnet center in range 4.903–10.212 mm
- F magnet half-aperture 31.850 mm
- F pipe cannot extend beyond [-21.638, 36.753] mm
- D pipe cannot extend beyond [-7.416, 84.726] mm
 - Not a problem on the outside

Beam Pipe in F Magnet



Beam Pipe in F Magnet




Injection

- Must inject beam at all energies
 - Determine lattice parameters vs. energy
- Acceleration: go from low energy to high
 - Beam moves outward
- Only injection from outside possible
- Septum outside 20 MeV beam


Doublet Symmetry

- Either D or F near septum
- D pushes beam out toward septum
- F pulls beam out to in toward septum
- Beam further out in F when F near septum
- Injection w/ F near septum: low energy beam too far out
 - Hits either D/F at inside, or F at outside
 - Lower energy bent more

Injection with F near Septum




Injection with D near Septum



Extraction

- Extraction has F near septum
- Beam never above extraction energy
- Move septum near extracted beam
 - Closer distance, less kick strength
- Stray fields: keep septum far (color: 10 mT!)
 - Too far, won't clear vacuum chamber
 - Low energy is limitation

Septum Stray Fields



Vector Fields
 software for electromagnetic design


Magnet Field Strengths

- Cell tune ≈ 0.25 : first kicker has no effect
 - Second kicker largest strength
- Lower energy: kickers opposite
 - Lower momentum easier
 - Two kickers best at phase advance $2\pi/3$
- Higher energy: kickers same direction
 - Two kickers best at phase advance $\pi/3$

Septum Position

- Septum closer: less oscillation amplitude
 - Smaller kicker fields
 - Further from pipe aperture
- Septum far away
 - Low energy: large oscillation
 - ✧ Hits pipe on inside
 - ✧ Hits F pipe on outside
 - High energy: large field to avoid F at outside
- 1.5 cm separation meets all requirements

Extraction Orbits




Kicker Jitter

- Kick not same every time
- Kickers send all amplitudes to same point
 - Extract line has small acceptance
 - Would have to kicker beam further otherwise
- Must predict betatron phase at extraction
- Tune shift with amplitude: prediction difficult
 - Larger number of betatron oscillations
 - Small amplitude error → large phase error


Tune Shift with Amplitude

- Relatively linear at high energies
- Larger, difficult to compute at low energy
- Cause is third-order resonance
- Relate kick error to phase error
- First turn contribution comparable to all subsequent turns


12 MeV Tune vs. Amplitude




10 MeV Tune vs. Amplitude



11 MeV Horizontal Phase Space



Tune Error vs. Energy



Kicker Error: Results

- 10 Gauss error, about 0.18 betatron oscillation error
 - Keep kicker errors low
 - Multiple runs, something will be close
- Depends strongly on precise magnet model

Conclusions

- Can extract from EMMA at any energy
 - All amplitude particles to same point
 - Extracted beam 1.5 cm outside circulating beam
 - Shielding needed for septum
- Injection kicker fluctuations
 - Tune shift with amplitude leads to large extraction error
 - Work on controlling, or live with